

APPLICATOR PARTS LIST

TYPE

SIDEWISE

.156 Dia.
Pin & Soc.AMP INCORPORATED
HARRISBURG, PENNA.

NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA			TERMINALS
1	WIRE CRIMPER Pin Δ	1	456411-6	42	Shear Plate - Left	1	454206-1	TO APPLY TERMINAL			Socket
2	INS. CRIMPER	1	2-473740-1	43	Shear Block - Right	1	386372				Feed
3	ANVIL	1	690386-1	44	Floating Shear	1	465406	WIRE SIZE	CRIMP HEIGHT		.660
4	ANVIL SPACER	1	811780-1	45	Retaining Plate - Front	1	811714-3	12	.087	Δ	61210
5	SHEAR BLADE			46	Retaining Plate - Rear	1	810822-1				
6	REAR SHEAR PLATE			47	Spring - Shear Return	1	374322	10	.106		
7	SHEAR BLADE SPACER			48	Shear - Depressor	1	811946-3				
8	FRONT SHEAR PLATE			49	Key - Shear Retainer	1	386358				
9	REAR ANVIL SPACER PLT.			50	Guard Mount	1	811306-1	CRIMP	SIZE	TYPE	FEED
10	FRONT Strip Hold	1	811593-3	51				WIRE	.140	F	.660
11	TOOL SPACER Pin Δ	1	387744	52				INSUL.	.210	F	2
12	CRIMP SPACER	1	370827	53				SLEEVED			.500
13	FRONT STRIP GUIDE	1	810971-6	54	Rear Strip Guide Spacer	1	811527-2	INSULATION RANGE	WIRE RANGE		
14	REAR STRIP GUIDE	1	465440-8	55	Hold Down Ass'y.	1	811849-1	.185 Max.	12 - 10	Δ	61211
15	RAM 473699	1	473699	56	Holder	1	811850-1	EXPLODED VIEW			
16	TOOL HOLDER			57	Cover	1	811851-1	A-6002-4-6			
17	ADJ. CRIMP MOUNT Ass'y.	1	465392-9	58	Blade	1	811852-1	REMARKS:			
18	ADJ. BLOCK			59	Spring	1	6-22279-6	Δ Mounts on Item 13			
19	APPLICATOR MOUNT ASSY.			60	Fl. Hd. Soc. Cap. Scr. & lg.	1	1-21003-8	Top Tool Mounting Sequence			
20	BASE PLATE	1	465100	61				From Ram Outward: Item			
21	BASE BLOCK	1	465101	62	WIRE CRIMPER Soc. Δ	1	453941-0	55, 11, 12, 17 & 48.			
22	STRIP GUIDE PLATE	1	465513-4	63	TOOL SPACER Soc. Δ	1	470493-6	Δ 61210 USE 62 & 63			
23	ANVIL HOLDER			64				61211 USE 1 & 11			
24	Wire Stop Guide	1	811787-2	65	Tension Adj. Plate	1	374999	INACTIVE			
25	STRIPPER - Wire Stop	1	386361-1	66	2" Dia. Reel Spooler Ass'y	1	453596-1	FOR REPLACEMENT ONLY			
26	STRIPPER MOUNT	1	386362	67				DENOTES WEARING PARTS			
27	RETAINER PLATE	1	389078	68				RECOMMEND PURCHASE REPLACEMENT			
28	STRIPPER MOUNT BRACKET	1	387715-1	69	Paper Separator	1	674927-1	THIS APPLICATOR IS TO BE USED ON			
29	STRIPPER BUSHING	1	389049-1	70				AMP-O-LECTRIC 1-471273-3			
30	STOCK DRAG	1	386955	71				DIST. 4			
31	STOCK DRAG HANDLE			72				SERIAL NO.			
32	STOCK DRAG STUD 374900	1	374900	REV.	REVISION RECORD	DATE	BY	ECN	DATE SHIPPED		
33	STOCK DRAG SPRING 370572	1	370572	A	SUPERSEDES 545793-3	10-16-68	RB	16253	CUSTOMER NAME AND ADDRESS		
34	STOCK DRAG ADJ. SCREW Nut	1	21022-3	B	32, 33 & FEED	6-3-69	RB	46692	DESIGNED		
35	FEED FINGER HOLDER	1	386942	C	ITEM 10 WAS -1 42 WAS RISES	5-20-70	RB	47551	CHK		
36	FEED FINGER	1	386941	D	PER ECN	9-10-70	RB	47774	APP'D		
37	FEED FINGER TIP	1	387251	E	REV PER SUPP	8-16-71	RB	48332	SHEET		
38	FEED FINGER SCREW Guide	1	689915-2	F	HARDWARE WAS 687509-1	1-3-72	RB	48659	1 OF 1		
39	BASE CASTING	1	570238	G	REV. PER ECN	3-20-72	RB	48781	APPLICATOR		
40	GUARD 457665-2	1	457665-2	H	REV PER ECN	4-2-73	RB	49621	NUMBER		
41	Bracket Guard	1	811304-1	J	ADD ITEM 62 & 63	8-23-74	RB	49724	REV.		
	K EC A-360692			JT	INACTIVE - FRD	2-24-77	RB	49724	K 565793-4		

Use Hardware Sheet 1-687511-8

OK

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[TE Connectivity:](#)

[565793-4](#)