

P2	REV PER ECU R-5079	RUEY PUA ECJ
P1	REV PER ECU E-5106	RUEY N
P2	REV PER ECU R-5079	RUEY PUA ECJ
P1	REV PER ECU E-5106	RUEY N

**TYPE**

**HTINGEBAR**

Fig. Sed.  
Mark III

**AMP INCORPORATED  
HARRISBURG, PENNA.**

NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA				TERMINALS	
1	WIRE CRIMPER	1	471788	42	Front Stab. Bar	1	811006-1	TO APPLY TERMINAL				1887	
2	INS. CRIMPER	1	472122	43	Anvil Insert Spacer							1888	
3	ANVIL	1	388623	44	Hinge Block & Stab.	1	810974-1	WIRE SIZE	CRIMP HEIGHT			1889	
4	ANVIL SPACER Insert	1	811045-1	45	Hinge Pin	1	811007-1	18	.052			2188	
5	SHEAR BLADE	1	810395-	46	Guard Front Stab.	1	811040-1	16	.056			2226	
6	REAR SHEAR PLATE	1	811068-1	47	Hinge Bar Assy. 565042-1	1	465248-1	14	.062			2187	
7	SHEAR BLADE SPRING	1	810410-1	48	Hinge Bar Spring 823046-5	2	811073-1	12	.072			60976	
8	FRONT SHEAR PLATE	1	388632-2	49	Strip Guide Stop	2	810417					61902	
9	REAR ANVIL SPACER PLT.			50	Strip Hold Down			CRIMP	SIZE	TYPE	FEED	63053	
10	FRONT ANVIL SPACER PLT.			51	Spacer-Comp. Spring	2	811070-1	WIRE	.160	188	.480		
11	TOOL SPACER			52	Cam Follower Holder	1	810409	INSUL.	.180	0			
12	CRIMP SPACER			53	Cam Follower 24746-1	1	372230	SLEEVED					
13	FRONT STRIP GUIDE	1	811166-1	54	Spring Bracket	1	810418	INSULATION RANGE					
14	REAR STRIP GUIDE	1	388621-1	55	Cam Follower Spring	1	810408	WIRE RANGE					
15	RAM	1	473828	56	Hook Holder	1	810419	EXPLODED VIEW					
16	TOOL HOLDER Ram Ret. Pl.	1	465004-2	57	Shear Pick-Up Hook	1	810416	A-6004-3 A-6004-4				1892	
17	ADJ. STRIP MOUNT Plate	1	811010-1	58	Hold Down-Hinge Bar	1	811009-1	REMARKS				1893	
18	ADJ. STRIP MOUNT Protective Plug	1	23141-1	59	Depressor Screw	1	810642-1	END WIRE APPLICATOR				1894	
19	APPLICATOR MOUNT ASSY.			60	Washer	4	376482					2189	
20	BASE PLATE	1	465238-1	61	Feed Finger Spring	1	810421-1					2190	
21	BASE BLOCK			62	Dowel Pin 1-21030-5	2	810426-1					2191	
22	STRIP GUIDE PLATE			63	Micro-Switch 23496-1	1	811069-1					22851	
23	ANVIL HOLDER	1	810423	64	Micro-Switch Cover	1	22609-2					42903	
24	AUX. ANVIL HOLDER			65	Bracket-Micro Switch	1	811074-1					63262	
25	STRIPPER			66	CONNECTOR	1	22787-2						
26	STRIPPER MOUNT			67	Hook Holder Screw	1	810413						
27	RETAINER PLATE			68	Feed Finger	1	811223-1						
28	STRIPPER MOUNT BRACKET			69	Spacer (Anvil Holder)	1	465918-1						
29	STRIPPER BUSHING			70	Lead Wire	1	465702-1						
30	STOCK DRAG	1	811167-1	71	Dowel Pin	1	465702-1						
31	STOCK DRAG HANDLE			72	Control Reel Supt. Assy.	1	465702-1						
32	STOCK DRAG STUD			REV. REVISION RECORD			DATE	BY	ECN				
33	STOCK DRAG SPRING	2	810135	D	RETRD - P. MOVE ITEM #63	11-30-45							
34	STOCK DRAG ADJ. SCREW			E	ITEM # 35 WAS 810414	6-30-67			1-4850				
35	FEED FINGER HOLDER	1	810131	F	REV PER ECN	11-30-67							
36	FEED FINGER	1	810422	FI	ADDED CRIMP HEIGHT	8-23-63			1-5740				
37	FEED FINGER TIP	1	810396	G	ADDED ITEM 68	6-5-69			1-5783				
38	FEED FINGER STUD	1	810414-1	H	SEE ECN	9-12-68			1-6138				
39	BASE CASTING	1	570238	J	REV PER ECN	5-26-69			1-5729				
40	GUARD, ASSY. 46704-4	1	46704-4	JI	ADD PT = 61902	8-26-70			1-7439				
41	Guard Insert	1	810392	K	REV PER ECN (SUPP)	8-4-71			1-7159				
K1	MODEL TERM 42903	1-14-72	1-898	L1	INACTIVATED	10-2-73			R73				
L	GUARD WBS 462050	11-17-72	1-9520	L2	REACTIVATED	5-16-71			R47				
								RECOMMENDED SPARE PARTS					
								THIS APPLICATOR IS TO BE USED ON					
								AMP-O-ELECTRIC 471273-3					
								AMP-O-MATIC					
								SERIAL NO.				DATE SHIPPED	DESIGNED
								CUSTOMER NAME AND ADDRESS					CHK'D BY
													APP'D
								APPLICATOR NUMBER				565510-1	SHEET 1 of 1
								For Hardware See 687520-2					

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[TE Connectivity:](#)

[565510-1](#)