

# KNOBS AND DIAL PLATES

## KNOBS



Part Number	1910DG	1400R	1202BJ	1930BP	1922	1914N
Switch Type	Rotary	Rotary	Rotary	Rotary	Rotary	Rotary
Shaft Diameter	0.125	0.125	0.250	0.250	0.250	0.250
Description	Inner knob with skirt and spun silver color cap	Pointer knob with one set screw	Round knob with spun silver color cap and one set screw	Large round knob with skirt and one set screw	Outer knob for dual concentric designs	Round knob with brass insert and one set screw
Overall Length	0.75	0.82	0.75	1.50	1.06	0.75

## KNOBS



Part Number	2300	2350AP	5149A	SSKW	SSKB	
Switch Type	Rotary	Rotary	Lever	Lever	Lever	
Shaft Diameter	0.250	0.250	0.187x0.050	0.187x0.060	0.187x0.060	
Description	Pointer knob with one set screw	Round knob with brass insert and two set screws	Oval knob push on design	Switch tip push on design-white	Switch tip push on design-black	
Overall Length	1.25	2.00	0.79	0.35 Dia.	0.35 Dia.	

## DIAL PLATES



Part Number	P173	P230	P232	P231	P115	P117	P118	P112
Switch Angle	15°	20°	20°	20°	30°	30°	30°	30°
Numbering Description	1-23	1-5	1-8	1-17	1-5	1-10	1-11	1-12
Plate Diameter	1.87	2.75	2.75	2.75	1.87	1.87	1.87	1.87

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Electroswitch:](#)

[2300](#) [P2300](#)