AMPROBE®

PRM-2 & PRM-3 Phase Sequence & Motor Rotation Tester



- Phase sequence indication of the three phase electrical systems
- Phase voltage loss or voltage sag indication
- Check for normal or reversed phases
- Three phase motor rotation indication (PRM-3 only)
- Extremely simple to use
- CAT III 600V

FEATURE	PRM-2	PRM-3
Identifies the phase sequence of the three phase electrical system	V	√
Checks motors for rotation direction		V
Indicates normal or reversed phases as well as loss of the phase	V	V
Voltage range	100 - 600V	50 - 600V

45 - 65 Hz



Frequency range

Miramar, FL 33025 • Toll Free: 800-327-5060 • Phone: 954-499-5400 • Fax: 954-499-5454 • www.Amprobe.com

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

AMPROBE: PRM-3 PRM-2