

# **IR Remote Control**

**P/N 559000105-3/559000106-3**

**Manual**

## Table of Contents

|                                |   |
|--------------------------------|---|
| <b>Introduction</b>            | 3 |
| <b>Function Key definition</b> | 5 |
| <b>Dimensions</b>              | 7 |
| <b>Specification</b>           | 8 |
| <b>Contact Details</b>         | 9 |

## Introduction

The Digital View Remote control unit is compatible with all DV controller products. It is provided with universal control buttons that enable the control of OSD functions plus TV and media playback on DV media products.

Remote Control Unit (without DV Logo) : P/N 559000106-3,

Remote Control Unit (with DV Logo) : P/N 559000105-3,


- **Infra-red (IR)** - Supports IR control with DV remote control handset (P/N: 559000106-3). The IR sensor and cable kit (P/N: 446010401-3) are required.
- **Product Supported:**  
DV Controller: DD-2000, DVS-1600, SP-1600, SVH-1920, SVH-1920+, SVX-1920 and HE series controllers.  
DV Media Player: ViewStream™ 100, ViewStream™ 300, ViewStream™ 500, M3-100, M3-300, M3-310 & RM-DN5.  
DV VideoFlyers™ : ALL




- **Battery installation:**

- Remove the cover of the remote control
- Load the batteries (2 x AAA), make sure that they are in right position.
- Close the battery cover.


1. Open the battery cover.



2. Insert batteries



3. Close the battery cover



Note :


1. Do not subject the remote control to water and shock.
2. Remove the batteries if you will not use the remote control for an extended period of time.
3. Incorrect use of batteries may cause damage to the remote control unit. Read the battery instruction and use the batteries properly.
4. Do not use a new battery with an old one.
5. Do not heat, disassemble, short circuit or throw batteries into a fire.

**CAUTION:** Do not attempt to remove any part of the casing or internal parts.

**Service & Warranty:** Warranty is invalidated if the unit is dismantled in any way. The unit is not user serviceable or repairable.


## 2 Function Key explanations

Keys for DV Controller:



| Key | Type / Use   |
|-----|--|
| 1   | Soft Power On/OFF  |
| 2   | Swap input source  |
| 3   | Zoom Image   |
| 4   | Move Up/down/Left/Right (in OSD) & Hot Key                                       |
| 5   | Previous OSD page  |
| 6   | Direct hot key for signal source   |
| 7   | (Attention + key "1") IR enable/Disable<br>(SVH-1920, SVH-1920+ & SVX-1920 only) |
| 8   | Mute   |
| 9   | PIP<br>(SVH-1920, SVH-1920+ & SVX-1920 only)                                     |
| 10  | Display information  |
| 11  | Next OSD page  |
| 12  | Volume Control   |

Keys for DV Player:



| Key | Type / Use                              |
|-----|---|
| 13  | Play                                    |
| 14  | Stop                                    |
| 15  | (Attention + Key "3") IR enable/disable |
| 16  | Track number (Direct access)            |
| 17  | Mute                                    |
| 18  | OSD On/Off                              |
| 19  | Previous track                          |
| 20  | Volume Control                          |
| 21  | Next track                              |
| 22  | Repeat                                  |
| 23  | Pause                                   |

### 3 Dimensions



**Notes:**

- Dimensions are in mm.
- Drawing is not to scale.

## 4 Specifications

|                          |  |
|--------------------------|--|
| Operating voltage:       | DC 3V  |
| Operating voltage range: | DC 2.25V-3.6V  |
| Operating temperature:   | 0° C ~ 45° C   |
| Operating current:       | ≤30mA  |
| Power source:            | 2 x AAA size batteries   |
| Number of keys:          | 38   |
| Oscillation frequency:   | 37.92KHz±3%  |
| Arrival distance:        | 8 m  |
| Accessories:             | Infra-red sensor (446010401-3)(order separately),<br>Batteries (AAA) |
| Dimensions :             | 158mm(H) x 45mm (W) x 21mm (D)                                       |
| Weight:                  | Approx, 55g (without batteries)                                      |



**CONTACT DETAILS**

**ASIA:** Digital View Ltd  
16<sup>th</sup> floor, Millennium City 3  
370 Kwun Tong Road  
Kwun Tong  
Hong Kong

**Tel:** (852) 2861 3615

**Fax:** (852) 2520 2987

**Sales:** [hksales@digitalview.com](mailto:hksales@digitalview.com)

**EUROPE:** Digital View Ltd  
6 Marylebone Passage  
London  
W1W 8EX  
UK

**Tel:** (44) (0)20 7631 2150

**Fax:** (44) (0)20 7631 2156

**Sales:** [uksales@digitalview.com](mailto:uksales@digitalview.com)

**USA:** Digital View Inc.  
18440 Technology Drive  
Building 130  
Morgan Hill, CA 95037

**Tel:** (1) 408-782 7773

**Fax:** (1) 408-782 7883

**Sales:** [ussales@digitalview.com](mailto:ussales@digitalview.com)

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Digital View:](#)

[559000106-3](#)