

APPLICATOR PARTS LIST

TYPE

SIDEWISE

TERMI - FOIL CONTACT

AMP INCORPORATED HARRISBURG, PENNA.

NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA	TERMINALS
1	WIRE CRIMPER	1	453946-2	42	GUARD MT.	1	811306-1	TO APPLY TERMINAL	
2	INS. CRIMPER			43					
3	ANVIL	1	458906-2	44	SPRING - SHEAR	1	387083	WIRE SIZE	CRIMP HEIGHT
4	ANVIL SPACER			45				12	.111
5	SHEAR SPR FLOATING	1	689931-3	46				10	.124
6	REAR SHEAR PLATE	1	811239-1	47				CRIMP	SIZE
7	SHEAR BLADE SPACER			48				WIRE	TYPE
8	FRONT SHEAR PLATE			49				INSUL.	FEED
9	REAR ANVIL SPACER PLT.			50				SLEEVED	
10	FRONT ANVIL SPACER PLT.			51				INSULATION RANGE	WIRE RANGE
11	TOOL SPACER	2	378246	52				W	12-10
12	CRIMP SPACER			53				EXPLODED VIEW	
13	FRONT STRIP GUIDE	1	692949-5	54				A - 6089	
14	REAR STRIP GUIDE	1	458908-1	55				REMARKS	
15	RAM	1	473699	56				Δ REVERSE BRACKET	
16	TOOL HOLDER			57				471799 (180°)	
17	ADJ. CRIMP MOUNT			58				Δ REMOVE AIR PLUG	
18	ADJ. BLOCK			59				FROM AIR CYL (LEFT REAR)	
19	APPLICATOR MOUNT ASSY.			60				MUST LAY WIRE IN	
20	BASE PLATE	1	465100-2	61				BARREL	
21	BASE BLOCK	1	692793-2	62				Δ PRINT OF ASSY ITEM (72)	
22	STRIP GUIDE PLATE	1	458910-1	63	BRACKET, AIR FEED SUP.	1	692036-1	MUST ACCOMPANY LOG SHEET	
23	ANVIL HOLDER	1	458909-1	64	1" AIR FEED Δ	1	690021-1		
24	AUX. ANVIL HOLDER	1	458907-1	65	TENSION ADJ. PL.	1	374999		
25	STRIPPER	1	386361-1		MISCELLANEOUS				
26	STRIPPER MOUNT	1	386362	66	LUBRICATOR ASSY.	1	464519-2		
27	RETAINER PLATE	1	389078	67	TERMINAL LUBRICANT	1	22014-1		
28	STRIPPER MOUNT BRACKET	1	387715-1	68	SPREADER ASSY.	1	453596-1		
29	STRIPPER BUSHING	1	389049-1	69	BRACKET, STOCK GUIDE	1	694927-4		
30	STOCK DRAG	1	387650-4	70	EXTENSION, REEL BRKT	2	455807-2		
31	STOCK DRAG HANDLE			71					
32	STOCK DRAG STUD	1	374900	72	BENDING FIXTURE ASSY	1	68196-1		
33	STOCK DRAG SPRING	1	370572		REV. REVISION RECORD	DATE	BY	ECN	
34	STOCK DRAG ADJ. SPACER NUT	1	21022-3		A	REV. PER ECN	2-25-76	JG	R1555
35	FEED FINGER HOLDER	1	386942		A1	INACTIVE	2-24-77	CE	R1983
36	FEED FINGER	1	473739-1		B	REACTIVATE W/CHANGES	8-17-81	CE	R4128
37	FEED FINGER TIP	1	387251		C	REV PER ECN	2-82	CE	4333
38	FEED FINGER SPACER				D	ECR-08-018679	7-08	TM	
39	BASE CASTING	1	570238						
40	GUARD 457665-8	1	811303-1						
41	GUARD BRACKET	1	811304-1						

CUSTOMER AND ASSEMBLY DRAWING

RESTRICTED TO

FOR HARDWARE
SEE 687524-2

00779

DIST. 4

SERIAL NO. DATE SHIPPED DESIGNED
RUSSELL 7-23-73
BENNETT

CUSTOMER NAME AND ADDRESS CHK'D.
1-25-73

APP'D.
1-25-73

APPLICATOR NUMBER REV D 566138-1 SHEET 1 OF 1

COPYRIGHT 1979

AMP INCORPORATED HARRISBURG, PENNA.

THIS IS A CONTROLLED DOCUMENT

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[TE Connectivity:](#)

[566138-1](#)