



# Addendum to MC9S08EL32 Series Data Sheet

## Clarifications for MC9S08EL32/16 and MC9S08SL16/8

This addendum document describes clarifications to the *MC9S08EL32 Series Data Sheet* (document number: MC9S08EL32). For convenience, the addenda items are grouped by revision.

### Contents

1	Clarifications for Revision 3 . . . . .	2
2	Addendum for Revision 3 . . . . .	2
3	Revision History . . . . .	2

# 1 Clarifications for Revision 3

The following specifications apply to the MC9S08EL32/16 and MC9S08SL16/8.

C	Characteristic	Symbol	V <sub>DD</sub> (V)	Typ	Max	Unit
P <sup>1</sup>	Stop3 mode supply current 125 °C (M suffix only)	S3I <sub>DD</sub>	5 3	60 55	110 105	μA
P <sup>1</sup>	Stop2 mode supply current 125 °C (M suffix only)	S2I <sub>DD</sub>	5 3	50 45	100 95	μA

<sup>1</sup> Stop currents are tested in production for 25°C on all parts. Tests at other temperatures depend upon the part number suffix and maturity of the product. Freescale may eliminate a test insertion at a particular temperature from the production test flow once sufficient data has been collected and is approved.

# 2 Addendum for Revision 3

Table 1. MC9S08EL32 DataSheet Revision 3 Errata

Location	Description
Section "SLIC During Break Interrupts"	Remove section "SLIC During Break Interrupts" on MC9S08EL32 Data Sheet. This functionality does not exist on the 9S08EL/SL family.

# 3 Revision History

Table 2 provides a revision history for this document.

Table 2. MC9S08EL32AD Revision History

Rev. Number	Substantive Changes	Date of Release
1	Remove Section " SLIC During Break Interrupts" in MC9S08EL32 Data Sheet.	12/2011

## **How to Reach Us:**

### **Home Page:**

[www.freescale.com](http://www.freescale.com)

### **Web Support:**

<http://www.freescale.com/support>

### **USA/Europe or Locations Not Listed:**

Freescale Semiconductor, Inc.  
Technical Information Center, EL516  
2100 East Elliot Road  
Tempe, Arizona 85284  
1-800-521-6274 or +1-480-768-2130  
[www.freescale.com/support](http://www.freescale.com/support)

### **Europe, Middle East, and Africa:**

Freescale Halbleiter Deutschland GmbH  
Technical Information Center  
Schatzbogen 7  
81829 Muenchen, Germany  
+44 1296 380 456 (English)  
+46 8 52200080 (English)  
+49 89 92103 559 (German)  
+33 1 69 35 48 48 (French)  
[www.freescale.com/support](http://www.freescale.com/support)

### **Japan:**

Freescale Semiconductor Japan Ltd.  
Headquarters  
ARCO Tower 15F  
1-8-1, Shimo-Meguro, Meguro-ku,  
Tokyo 153-0064  
Japan  
0120 191014 or +81 3 5437 9125  
[support.japan@freescale.com](mailto:support.japan@freescale.com)

### **Asia/Pacific:**

Freescale Semiconductor China Ltd.  
Exchange Building 23F  
No. 118 Jianguo Road  
Chaoyang District  
Beijing 100022  
China  
+86 10 5879 8000  
[support.asia@freescale.com](mailto:support.asia@freescale.com)

### **For Literature Requests Only:**

Freescale Semiconductor Literature Distribution Center  
P.O. Box 5405  
Denver, Colorado 80217  
1-800-441-2447 or +1-303-675-2140  
Fax: +1-303-675-2150  
[LDCForFreescaleSemiconductor@hibbertgroup.com](mailto:LDCForFreescaleSemiconductor@hibbertgroup.com)

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.



Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2010. All rights reserved.

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

## [NXP:](#)

[MC9S08EL16CTJ](#) [MC9S08EL16CTL](#) [MC9S08EL32CTJ](#) [MC9S08EL32CTL](#) [MC9S08SL16CTJ](#) [MC9S08SL16CTL](#)  
[MC9S08SL8CTJ](#) [MC9S08SL8CTL](#) [S9S08EL32F1MTJ](#) [S9S08SL16F1MTJ](#) [S9S08SL16F1MTL](#) [S9S08EL32F1MTJR](#)  
[S9S08SL8F1MTL](#) [S9S08SL16F1CTJ](#) [S9S08SL8F1CTJ](#) [S9S08SL8F1CTL](#) [S9S08EL32F1MTL](#) [S9S08SL16F1MTLR](#)  
[S9S08SL8F1MTJR](#) [S9S08SL8F1CTJR](#) [S9S08SL8F1MTJ](#) [S9S08EL32F1CTJR](#) [S9S08EL32F1VTLR](#)  
[S9S08SL16F1MTJR](#) [S9S08EL32F1CTLR](#) [S9S08EL16F1MTRL](#) [S9S08SL8F1MTRL](#) [S9S08EL16F1CTJR](#)  
[S9S08SL16F1VTLR](#) [S9S08EL16F1MTL](#) [S9S08SL16F1CTJR](#) [S9S08SL8F1VTJR](#) [S9S08EL16F1VTJR](#)  
[S9S08EL32F1VTL](#) [S9S08SL16F1VTL](#) [S9S08EL32F1MTRL](#) [S9S08SL16F1CTLR](#) [MC9S08EL16CTLR](#)  
[MC9S08SL8MTJ](#) [MC9S08SL8VTJ](#)