



SCOPE

SPECIFICATION SHEET T2 Terminator 63850-2200 REVISION A



Terminal Series No	Wire Size		Insulation Diameter		Strip Length	
	Awg	(mm²)	mm	(in)	mm	(in)
70058-00**	32-36	(0.03-0.01)	0.43-0.64	(.017025)	3.17-3.56	(.125140)
71851-001*	32-36	(0.03-0.01)	0.43-0.64	(.017025)	3.17-3.56	(.125140)

DEFINITION OF TERMS



The above terminal drawing is a generic terminal representation. It is not an image of a terminal listed in the scope

Page 1 of 5 UNCONTROLLED COPY



SPECIFICATIONS

Terminal Series No	o. Belli	Bellmouth		Cut-Off Tab Max.		Conductor Brush	
	mm	(in)	Front mm (in)	Rear mm (in)	mm	(in)	
70058-00**	0.20-0.50	(.008020)	0.13 (.005)	0.08 (.003)	0.00-1.00	(.000039)	
71851-001*	0.20-0.50	(.008020)	0.13 (.005)	0.08 (.003)	0.00-1.00	(.000039)	
	· · · · · · · · · · · · · · · · · · ·						

Terminal Series N	Io. Bend Up	Bend Down	Twist	Roll	Punch W	idth mm
	D	egree	De	gree	Conductor	Insulation
70058-00**	3	3	3	8	0.90	1.40
71851-001*	3	3	3	8	0.90	1.40

The above specifications are guidelines to an optimum crimp.

CONDITIONS

After crimping, the conductor profile should measure the following.

Terminal Series	Wire Size		Crimp Height		Pull Force Min	
	Awg	(mm²)	mm	(in)	Ν	(lbs)
70058-00**	32	(0.03)	0.64-0.66	(.025026)	4.4	(1.0)
70058-00**	34	(0.02)	0.61-0.64	(.024025)	2.7	(0.6)
70058-00**	36	(0.01)	0.61-0.64	(.024025)	1.8	(0.4)
71851-001*	32	(0.03)	0.64-0.66	(.025026)	4.4	(1.0)
71851-001*	34	(0.02)	0.61-0.64	(.024025)	2.7	(0.6)
71851-001*	36	(0.01)	0.61-0.64	(.024025)	1.8	(0.4)
					· · · · · · · · · · · · · · · · · · ·	

Pull Force measured with no influence from the insulation crimp

Page 2 of 5 UNCONTROLLED COPY



PARTS LIST

Item Number	Order Number	Eng Number	Description	Qty	Kit Part
1	634440914	634440914	Conductor Punch	1	Y
2	634450931	634450931	Conductor Anvil	1	Y
3	634461419	634461419	Insulation Punch	1	Y
4	634451425	634451425	Insulation Anvil	1	Y
5	634430003	634430003	Cut-Off Plunger	2	Y
6	634430012	634430012	Front Plunger Retainer	1	Y
16	634431402	634431402	Cut-off Die Blade	1	Y
20	634431002	634431002	Rear Plunger Retainer	1	Y
7	11-24-1067	4996-4	Cut-Off Plunger Spring	2	
8	11-40-4039	8302-5	Front Plunger Striker	1	
9	634430021	634430021	Lower Tooling Key	1	
10	634436003	634436003	Rear Cover	1	
11	11-18-4094	60709A111	Front Cover	1	
13	638008503	638008503	Wire Stop	1	
15	638008500	638008500	T2 Terminator	1	
32	638008502	638008502	Rear Plunger Striker	· 1	
36	634432102	634432102	Front Spacer	1	
37	634432103	634432103	Rear Spacer	1	
38	11-24-1149	4996-37	Shank	1	
39	11-40-4274	8331-8	Hold Down Blade	1	
42	11-17-0022	1739-21	Hold Down Spring	1	
50	638602015	638602015	Drag Frame	1	
70	638502270	638502270	Tool Kit (All "Y" Items)	0	

NOTES


- 1. We recommend an extra perishable tooling kit be maintained at your facility.
- 2. Verify tooling alignment by manually cycling the press and Terminator before crimping under power.
- 3. Slugs, Terminals, Dirt and Oil should be kept clear of work area.
- 4. This Terminator should only be used in a Molex TM42, TM40, or 3BF Press with a BaseUnit adaptor.
- 5. ** CAUTION** To prevent injury never operate this Terminator without the guarding supplied with the TM42, TM40, or 3BF Press / Base Unit.
- 6. Wear safety glasses at all times.



Page 3 of 5 UNCONTROLLED COPY

ASSEMBLY DRAWING

The drawing below is a generic drawing representation. Some detail may not be shown. The T2 Terminator assembly and parts list can be found in the T2 Terminator manual.




Doc No 638502200 - Rev A 99/08/09

Note

Depending on the press vintage a feed finger assembly is supplied with the T2 Terminator.

- 1. To remove the existing feed finger assembly loosen the M4 x 10 mm set screw in the feed lever.
- 2. Select T2 Feed finger assembly from Terminator box
- Insert a screwdriver into to slot behind the feed lever and force the 12 mm spring to the right.
- 4. Slide the T2 feed finger shaft for TM42 (11-40-5307) or (11-40-0123) for TM40 /Base Unit into the feed lever and to the left of the 12 mm spring.
- 5. Release the 12 mm spring.
- 6. Position feed finger for selected product. (Ref fig 5.1 T2 Manual)



TM42 Press

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Molex: 63850-2270