


Application Tooling Specification Sheet



Order No. 63911-8900

FEATURES

T2 Terminator Tooling


- Ideally suited for mid-volume bench operations
- Terminator can be installed in the TM42 and the TM40 press or Base Unit adapter for 3BF press
- Quick punch removal with the push of a button for fast and easy tooling change
- Track adjustment capabilities in the T2 Terminators for improved control of the bell mouth size and cut-off tab length
- T2 Terminator has standardized tooling with the Molex FineAdjust Applicator, which will reduce your inventory requirements

SCOPE

Products: Micro-Fit 3.0 Crimp Terminal, Male and Female, 20-24 AWG.

Terminel			Wire Size			Insulation	Strip Length			
Terminal Series No.	Terminal	Order No.	WITE OIZE		IPC/WHMA-A620 (1)		Termi	nal (2)	Strip Length	
Series NO.			AWG	mm²	mm	In.	mm	In.	mm	In.
	43030-0001	43030-0051	20-24	0.50-0.20	0.91-1.09	.036043	0.90-1.85	.035073	2.54-2.92	.100115
43030	43030-0002	43030-0052								
43030	43030-0003	43030-0053								
	43030-1001									
	43031-0001	43031-0051	20-24	0.50-0.20	0.91-1.09	.036043	0.90-1.85	.035073	2.54-2.92	
	43031-0002	43031-0052								.100115
43031	43031-0003	43031-0053								
	43031-0017	43031-0102								
	43031-0018	43031-0103								
44372	44372-0002	44372-3606	20-24	0.50-0.20	1.10-1.30	.043051	0.90-1.85	.035073	2.54-2.92	.100115
45773	45773-0001	45773-0002	20-24	0.50-0.20	1.10-1.30	.043051	0.90-1.85	.035073	2.54-2.92	.100115
43773	45773-0003	45773-0053	20-24							
45807	45807-0004		20-24	0.50-0.20	1.10-1.30	.043051	0.90-1.85	.035073	2.54-2.92	.100115
(1) To achieve optimum IPC-A620 Class 2 insulation crimps, use this insulation OD range.										
(2) Overall insulation OD specification for terminal.										
Terminator 63911-8800 should be used for insulation OD 1.10-1.30mm (.043051 inch).										

Terminator 63910-4500 should be used for insulation OD 1.30-1.85mm (.051-.073 inch).



The above terminal drawing is a generic terminal representation. It is not an image of a terminal listed in the scope.

CRIMP SPECIFICATION

Torm	inal Soria	e No	Bell M	louth	Cut-Off Tak	o Maximum	Conductor Brush		
Tenn	Terminal Series No.			In.	mm In.		mm	ln.	
43030	43031	44372	0.05-0.40	.002016	0.15	.006	0.20-0.80	.008031	
45773	45807		0.05-0.40						

	Terminal Series No.		Bend Up Bend Down		Twist R	Roll	Punch Width mm (Ref)					
Termi			Denia op	Dena Down	i wist	1.011	Conductor		Insulation		Seam	
			Degree		Deg	ree mm l		In	mm In			
43030	43031	44372	0	3	4	•	1 40	055	4 40	055	Seam shall not be open	
45773	45807		3		4	ð	1.40	.055	1.40	.055	and no wire allowed out of the crimping area	

After crimping, the conductor profile should measure the following:


Terminal Series No.	Wire	Size	Conductor C	Crimp Height	Insulation C	rimp Height	Pull Force Minimum		
Terminal Series NO.	AWG	mm ²	mm	In.	mm	ln.	N	Lb.	
	20	0.50	0.91-0.99	.036039	2.30 max	.090 max	57.9	13.0	
43030	22	0.35	0.84-0.91	.033036	2.30 max	.090 max	35.6	8.0	
	24	0.20	0.79-0.84	.031033	2.30 max	.090 max	22.3	5.0	
	20	0.50	0.91-0.99	.036039	2.30 max	.090 max	57.9	13.0	
43031	22	0.35	0.84-0.91	.033036	2.30 max	.090 max	35.6	8.0	
	24	0.20	0.79-0.84	.031033	2.30 max	.090 max	22.3	5.0	
	20	0.50	0.91-0.99	.036039	2.30 max	.090 max	57.9	13.0	
44372	22	0.35	0.84-0.91	.033036	2.30 max	.090 max	35.6	8.0	
	24	0.20	0.79-0.84	.031033	2.30 max	.090 max	22.3	5.0	
	20	0.50	0.91-0.99	.036039	2.30 max	.090 max	57.9	13.0	
45773	22	0.35	0.84-0.91	.033036	2.30 max	.090 max	35.6	8.0	
	24	0.20	0.79-0.84	.031033	2.30 max	.090 max	22.3	5.0	
	20	0.50	0.91-0.99	.036039	2.30 max	.090 max	57.9	13.0	
45807	22	0.35	0.84-0.91	.033036	2.30 max	.090 max	35.6	8.0	
	24	0.20	0.79-0.84	.031033	2.30 max	.090 max	22.3	5.0	

Tool Qualification Notes

- 1. Pull force should be measured with no influence from the insulation crimp.
- 2. The above specifications are guidelines to an optimum crimp.

PARTS LIST


T2 Terminator 63911-8900									
Item	Order No.	Quantity							
	Perishable Tooling								
	63911-8970	63911-8970	Tool Kit (All "Y" Items)	REF					
1	63444-1421	63444-1421	Conductor Punch	1 Y					
2	63445-1436	63445-1436	Conductor Anvil	1 Y					
3	63446-1406	63446-1406	Insulation Punch	1 Y					
4	63445-1409	63445-1409	Insulation Anvil	1 Y					
5	63443-0002	63443-0002	Front Cut-Off Plunger	1 Y					
6	63443-0012	63443-0012	Front Plunger Retainer	1 Y					
		Other Con	nponents						
7	11-18-4083	60707-8	Feed Guide	1					
8	11-24-1067	4996-4	Cut-Off Plunger Spring	1					
9	11-40-4039	8302-5	Plunger Striker	1					
10	63443-0009	63443-0009	Front Scrap Chute	1					
11	63443-0024	63443-0024	Кеу	1					
12	63443-0085	63443-0085	Wire Stop L-Bracket	1					
13	63443-0090	63443-0090	Wire Stop	1					
14	63443-1703	63443-1703	Height Spacer (17.30mm)	1					
15	63443-2216	63443-2216	Coarse Spacer (16.00mm)	1					
16	63443-2302	63443-2302	Fine Spacer (3.10mm)	1					
17	63443-6003	63443-6003	Rear Cover	1					
	-	Fra							
18	63800-8500	63800-8500	T2 Terminator	1					
		Hardy							
19	N/A	N/A	M3 by 6 Long SHCS	2**					
20	N/A	N/A	M3 by 6 Long FHCS	1**					
21	N/A	N/A	M4 by 6 Long SHCS	2**					
22	N/A	N/A	M4 by 12 Long BHCS	2**					
23	N/A	N/A	M4 by 14 Long SHCS	2**					
24	N/A	N/A	M4 by 45 Long SHCS	2**					
25	N/A	N/A	M5 by 12 Long SHCS	1**					
26	N/A	N/A	#10-32 by 3/8"Long BHCS	1**					
** Available from an industrial supply company such as MSC (1-800-645-7270).									



NOTES

Depending on the press vintage, a feed finger assembly is supplied with the T2 Terminator.

- 1. To remove the existing feed finger assembly, loosen the M4 x 10mm set screw in the feed lever.
- 2. Select the T2 feed finger assembly from the Terminator box.
- 3. Insert a screwdriver into the slot behind the feed lever, and force the feed arm spring to the right.
- 4. Slide the T2 feed finger shaft for the TM42 (11-40-5307) or (11-40-0123) for TM40 or Base Unit into the feed lever and to the left of the feed arm spring.
- 5. Release the feed arm spring.
- 6. Position the feed finger for the selected product (Refer to Figure 5.1 in the T2 Manual.).



NOTES

- 1. Molex recommends that an extra perishable tooling kit be maintained at your facility.
- 2. Verify tooling alignment by manually cycling the press before crimping under power. Check that all screws are tight.
- 3. Slugs, terminals, dirt and oil should be kept clear of the work area.
- 4. This Terminator should be only used in a Molex TM42, TM40 or 3BF Press with a Base Unit adaptor.
- 5. Wear safety glasses at all times.
- 6. For recommended maintenance, refer to the TM40, TM42 Manual.

CAUTION: To prevent injury never operate this Terminator without the guards supplied with the press in place. Reference the TM42 press manufacturer's instruction manual.

CAUTION: Molex crimp specifications are valid only when used with Molex terminals, applicators and tooling.

	CAUTION:
	Molex tooling crimp specifications are valid only when used with Molex terminals and tooling manufactured by Molex and sold by Molex or authorized distributors ("Molex Tooling").
	When using tooling other than Molex Tooling with Molex-specific connector systems listed in the ATS documents, the Molex Tooling qualification does not apply, and the responsibility for full qualification of the connector system is that of the customer.
	Molex accepts no liability for connector performance or tooling support where tooling other than Molex Tooling is used or where Molex Tooling is modified.
	CAUTION:
Â	A-620 and other industry standards do not supersede the manufacturer's specifications.
	Some terminals designed over 20 years ago may not meet the desired physical attributes for some of today's standards; however, these terminals will still perform electrically at an acceptable quality level based on qualification testing and years of successful performance in the field.
	Application Tooling Support

Phone: (402) 458-TOOL (8665) E-Mail: applicationtooling@molex.com Website: www.molex.com/applicationtooling

Molex is a registered trademark of Molex, LLC in the United States of America and may be registered in other countries; all other trademarks listed herein belong to their respective owners.

UNCONTROLLED COPY

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Molex: 63911-8970