

bq500410A bqTESLA™ Wireless Power Transmitter EVM

The bq500410AEVM-085 (EVM) wireless power transmitter evaluation module from Texas Instrument is a high-performance, easy-to-use development tool for wireless power solutions. The transmitter module is a complete solution allowing the designer to speed the development of their end-product. The bq500410AEVM-085 evaluation module (EVM) provides all basic functions for evaluation of the bq500410A IC in a fully functional wireless transmitter configuration, WPC A6 type. The bq500410A supports a three coil array for increased free positioning area. Any Qi-compliant receiver or bq51013AEVM-764, -765 receiver EVM's can be used for evaluation. The bq500410AEVM-085 is a 12-V input design with an optional boost converter for operation from 5 V.

Contents

1	Applications	2
2	bq500410AEVM-085 Electrical Performance Specifications	2
3	Modifications	2
4	Connector and Test Point Descriptions	3
	4.1 Input/Output Connections	3
	4.2 Test Point Descriptions	3
5	Schematic and Bill of Materials	5
6	Test Setup	10
	6.1 Equipment	10
	6.2 Equipment Setup	10
7	bq500410AEVM-045 Assembly Drawings and Layout	13
8	Reference	20

List of Figures

1	bq500410AEVM-085EVM Schematic, Page 1 of 3.....	5
2	bq500410AEVM-085 Schematic, Page 2 of 3	6
3	bq500410AEVM-085 Schematic, Page 3 of 3	7
4	Equipment Setup	11
5	Efficiency Versus Power Across Each Coil, bq500410AEVM-085 Transmitter and bq51013AEVM-764 Receiver	12
6	Efficiency Versus Power Center Coil 12-V Input Versus 5-V Input, bq500410-085 Transmitter and bq51013AEVM-764 Receiver	12
7	Placement	14
8	Assembly Top.....	15
9	Top Silk	16
10	Top Layer.....	17
11	Layer 2	18
12	Layer 3	19
13	Bottom Layer.....	20

List of Tables

1	bq500410AEVM-045 Electrical Performance Specifications	2
2	Bill of Materials	8

1 Applications

The bq500410AEVM-085 evaluation module demonstrates the transmitter portion of the bqTESLA™ wireless power system. This transmitter EVM is a complete transmitter-side solution that powers a bqTESLA™ receiver. All transmitter-side electronics and transmitter coils are on a single 4-layer printed circuit board (PCB). The open design allows easy access to key points of the electrical schematic:

- WPC certified transmitter
- WPC A6-type transmitter coil, 70 mm × 25 mm free positioning area
- Input voltage 12 V
- Optional boost converter to allow operation from 5 V
- Transmitter-coil mounting pad providing correct receiver interface
- LED indicates power transfer or fault state, and buzzer indicates start of power transfer

2 bq500410AEVM-085 Electrical Performance Specifications

Table 1 provides a summary of the bq500410AEVM-045 performance specifications. All specifications are given for an ambient temperature of 25°C.

Table 1. bq500410AEVM-045 Electrical Performance Specifications

Parameter		Notes and Conditions	Min	Typ	Max	Unit
Input Characteristics						
V_{IN}	Input voltage		0.6	12.0	0.6	V
I_{IN}	Input current	$V_{IN} = \text{Nom}$, $I_{OUT} = 1 \text{ A}$ at 5 V		570		mA
	Input no-load current	$V_{IN} = \text{Nom}$, $I_{OUT} = 0 \text{ A}$		75		mA
	Input stand-by current	$V_{IN} = \text{Nom}$		10		mA
Output Characteristics – Receiver bq51013AEVM-764, -765						
V_{OUT}	Output voltage	$V_{IN} = \text{Nom}$, $I_{OUT} = \text{Nom}$	4.5	5	5.1	V
	Output ripple	$V_{IN} = \text{Nom}$, $I_{OUT} = \text{Max}$			200	mV _{PP}
I_{OUT}	$V_{IN} = \text{Min to Max}$	$V_{IN} = \text{Min to Max}$	0		1	A
	Output overcurrent	$V_{IN} = \text{Nom}$	1		1.1	A
Systems Characteristics						
F_S	Switching frequency	Switching frequency varies with load	110		205	kHz
η_{pk}	Peak efficiency	$V_{IN} = \text{Nom}$, P Out RX = 2.5 W		74.2		%
η	Full-load efficiency	$V_{IN} = \text{Nom}$, $I_{OUT} = \text{Max}$		73.6		%

3 Modifications

See the data sheet ([SLUSB96](#)) when changing components.

- LED Mode--Resistor R39 can be used to change behavior of status LED D4. Standard value is 42.2 kΩ for control option 1, see data sheet for additional settings.
- NTC--Connector J6 provides the option for connecting a negative temperature coefficient (NTC) sensor for thermal protection, see data sheet for additional settings
- PMOD--Resistor R40 is used to set the loss threshold, standard value is 56.2 kΩ. Removing jumper JP1 disables PMOD. Resistor value can be changed to adjust the threshold, see data sheet for additional settings.

4 Connector and Test Point Descriptions

4.1 Input/Output Connections

The connection points are described in [Section 4.1.1](#) – [Section 4.1.8](#).

4.1.1 J1: Vin--12V

Input power 12 V \pm 600 mV, return at J2.

4.1.2 J2: GND

Return for input power, input at J1.

4.1.3 J3: Vin--5V

Input power 5 V return at J2.

4.1.4 J4: PMBus interface

Factory use only

4.1.5 J5: JTAG interface

Factory use only

4.1.6 J6: NTC

The connection point for an external temperature sensor. See the data sheet for more information.

4.1.7 JP1: Loss Threshold

With the jumper open, PMOD function is disabled. With shorting jumper installed, PMOD is enabled and resistor R40 sets the PMOD threshold, see data sheet for more information.

4.1.8 JP2: Select LED Mode

The connection point for an external resistor to select the LED mode. See the bq500410A data sheet for more information.

4.2 Test Point Descriptions

The test points are described in [Section 4.2.1](#) – [Section 4.2.8](#).

4.2.1 Ground Test Point

TP1: Analog Ground

TP29: Analog Ground

4.2.2 TPS54231 U3 Signal

TP30: Test point used for loop stability test of U3

TP31: 3V3_VCC 3.3 V out of DC to DC converter

4.2.3 INA199A1 U4 Signal

TP3: I_SENSE – Signal representing input current to coil drive circuit

4.2.4 bq500410A U9 Signals

TP14: U9 Pin 1 COMM+ peak detect input
TP17: DPWM output
TP2: COMM+ Signal output from MUX
TP4: COMM- Signal output from MUX

4.2.5 Coil L1 Signals

TP5: COMM select signal for Coil 1
TP6: Capacitor Side Drive signal to Coil 1
TP9: Switch Transistor Side Drive signal to Coil 1
TP10: PWR GND Coil 1

4.2.6 Coil L2 Signals

TP11: COMM Select signal for Coil 2
TP12: Capacitor Side Drive signal to Coil 2
TP16: Switch Transistor Side Drive signal to Coil 2
TP23: PWR GND Coil 2

4.2.7 Coil L3 Signals

TP25: COMM Select signal for Coil 3
TP26: Capacitor Side Drive signal to Coil 3
TP27: Switch Transistor Side Drive signal to Coil 3
TP28: PWR GND Coil 3

4.2.8 Unused Pins

TP7: U6 Pin 4, not used
TP8: U6 Pin 5, not used
TP13: U9 Pin 41, not used
TP15: U9 Pin 6, not used
TP18: U9 Pin 13, not used
TP19: U9 Pin 24, not used
TP20: U9 Pin 19, not used
TP21: U9 Pin 20, not used
TP22: U9 Pin 22, not used
TP24: U9 Pin 21, not used

5 Schematic and Bill of Materials




Figure 1. bq500410AEVM-085EVM Schematic, Page 1 of 3




Figure 2. bq500410AEVM-085 Schematic, Page 2 of 3




Figure 3. bq500410AEVM-085 Schematic, Page 3 of 3

Table 2. Bill of Materials

QTY	Ref Des	Value	Description	Size	Part Number	MFR
1	U1	TPS61087DSC	IC, 600 kHz/1.2 MHz Step-Up DC-DC Converter	SON-10	TPS61087DSC	TI
3	U2 U7 U10	TPS28225D	IC, High Frequency 4-Amp Sink Synchronous Buck MOSFET Driver	SO8	TPS28225D	TI
1	U3	TPS54231D	IC, 2-A, 28-V Input, Step-down Swift DC/DC Converter W/ eco-Mode	SO8	TPS54231D	TI
1	U4	INA199A1	IC, Current Monitor, High or Low Side Measurement, Bi-Directional Zero-Drift Series	SC-70	INA199A1DCKR	TI
3	U5 U8 U11	TS5A1066DBVR	IC, 10-Ω SPST Analog Switch	SOT23-5	TS5A1066DBVR	TI
1	U6	MSP430G2101	IC, Mixed Signal Microcontroller	TSSOP	MSP430G2101IPW14	TI
1	U9	bq500410ARGZ	IC, Qi Compliant Wireless Power Transmitter Manager	VQFN	bq500410ARGZ	TI
1	BUZ	Buzzer	Piezoelectronic, 12 mm	12 mm	PS1240P02CT3	TDK
2	C1-2	33 nF	Capacitor, ceramic, 50 V, X7R, 10%	0603	STD	STD
7	C3 C7 C9 C16 C32 C48 C59	22 μF	Capacitor, ceramic, 25 V, X5R, 20%	1210	Std	STD
1	C4	10 μF	Capacitor, ceramic, 35 V, X5R, 20%	1210	Std	STD
15	C5-6 C8 C13 C15 C17-19 C34-35 C52-54 C63-64	0.1 μF	Capacitor, ceramic, 50 V, X7R, 10%	0603	STD	STD
4	C11 C41 C47 C49	1.0 μF	Capacitor, ceramic, 16 V, X7R, 20%	0603	STD	STD
0	C12	Open	Capacitor, ceramic, 50 V, C0G, 5%	0603	STD	STD
3	C20 C44 C50	4.7 μF	Capacitor, ceramic, 10 V, X5R, 20%	0603	STD	STD
1	C21	2700 pF	Capacitor, ceramic, 50 V, C0G, 5%	0603	STD	STD
1	C22	47 μF	Capacitor, ceramic, 6.3 V, X5R, 20%	1206	STD	STD
3	C24 C10 C14	0.01 μF	Capacitor, ceramic, 50 V, X7R, 10%	0603	STD	STD
0	C25 C56 C31 C61	Open	Capacitor, ceramic, 100 V, C0G, 5%	1210	Std	STD
6	C28 C30 C42 C45 C58 C60	0.068 μF	Capacitor, ceramic, 100 V, C0G, 5%	1812	Std	Std
1	C29	1000 pF	Capacitor, ceramic, 16 V, X7R, 20%	0603	STD	STD
3	C36 C55 C23	33 pF	Capacitor, ceramic, 50 V, C0G, 5%	0603	STD	STD
1	C65	47 pF	Capacitor, ceramic, 50 V, COG, 5%	0603	STD	STD
1	C27	2200 pF	Capacitor, ceramic, 16V, X7R, 20%	0603	STD	STD
2	C38 C46	5.6 nF	Capacitor, ceramic, 100 V, C0G, 5%	1210	Std	STD
3	C39 C26 C57	4700 pF	Capacitor, ceramic, 50 V, X7R, 10%	0603	STD	STD
1	C40	330 pF	Capacitor, ceramic, 50 V, X7R, 10%	0603	STD	STD
2	C43 C37	4.7 nF	Capacitor, ceramic, 50 V, X7R, 10%	0603	STD	STD
3	C51 C33 C62	0.22 μF	Capacitor, ceramic, 50 V, X7R, 20%	0603	STD	STD
1	D1	SL22-E3/53T	Diode, Schottky, 2 A, 20 V	SMC	SL22-E3/53T	Vishay
1	D2	MBR0540	Diode, Schottky, 0.5 A, 40 V	SOD-123	MBR0540T1G	On Semi
1	D3	LTST-C190GKT	Diode, LED, Green, 2.1 V, 20 mA, 6 mcd	0603	LTST-C190GKT	Lite On
1	D4	LTST-C155KGJRKT	Diode, Dual LED, Water Clear, 80 mA, 35/25 mcd	0.126 x 0.106 in	LTST-C155KGJRKT	Lite On
4	D5-8	BAT54SW	Diode, Dual Schottky, 200 mA, 30 V	SOT523	BAT54SWT1G	On Semi
4	J1-3, J6	PEC02SAAN	Header, Male 2-pin, 100 mil spacing,	0.100 in x 2	PEC02SAAN	Sullins
1	J4	N2510-6002-RB	Connector, Male Straight 2 x 5 pin, 100 mil spacing, 4 wall	0.338 x 0.788 in	N2510-6002RB	3M
1	J5	N2514-6002-RB	Header, 2 x 7 pin, 100 mil spacing, straight, 4 wall	0.338 x 0.988 in	N2514-6002-RB	3M
2	JP1-2	PEC02SAAN	Header, Male 2-pin, 100 mil spacing,	0.100 in x 2	PEC02SAAN	Sullins
1	L1-3	TX Coil	WPC-Compliant A6 TX Coil Set	Note 1A	Y31-60037F	E&E
		TX Coil	WPC-Compliant A6 TX Coil Set	Note 1B	or 760308106	Würth Elektronik

Table 2. Bill of Materials (continued)

QTY	Ref Des	Value	Description	Size	Part Number	MFR
1	L4	330uH	Inductor, SMT, 155 mA, 1.8 Ω	0.189 x 0.189 in	LPS5030-334MLB	Coilcraft
		330uH	Inductor, SMT, 170mA, 1.7 ohm	4.8mm x 4.8mm	or 744043331	Würth Elektronik
1	L5	3.3uH	Inductor, SMT, 3.3uH, 4.2A, 24 mΩ	7.3mm x 7.3mm	7447789003	Würth Elektronik
2	Q1 Q9	BSS215P	MOSFET P-CH, 20 V, 1.5 A, SOT-23	SOT23	BSS215P	Infineon
6	Q2-7	CSD17308Q3	MOSFET, NChan, 30 V, 13 A, 9.4 mΩ	QFN3.3 x 3.3 mm	CSD17308Q3	TI
1	Q8	BC847CL	TRANSISTOR, NPN, HIGH-PERFORMANCE, 500 mA	SOT-23	BC847CLT1G	ON Semi
1	R1	18.2 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R2	158 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R3	16.2 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R5	0.02 Ω	Resistor, chip, 1/4W, 1%	0805	ERJ-6BWFR020V	Panasonic
1	R9	1.00 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R10	3.16 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R12	76.8 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
0	R17 R28 R19 R42 R44-45 R65	Open	Resistor, chip, 1/16W, 1%	0603	Std	Std
3	R18 R15-16	475 Ω	Resistor, chip, 1/16W, 1%	0603	Std	Std
3	R14 R36 R57	200 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
2	R23, R4 R6	1 Ω	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R26	49.9 Ω	Resistor, chip, 1/16W, 1%	0603	Std	Std
11	R29 R49-50 R22 R59, R7 R20 R32 R34 R53 R58	10 Ω	Resistor, chip, 1/16W, 1%	0603	Std	Std
3	R33 R8 R54	23.2 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R37	15.4 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R38	2.00 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R39	42.2 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R40	56.2 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R43	22 Ω	Resistor, chip, 1/10W, 1%	0805	STD	STD
1	R47	100 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
8	R52 R41 R60 R31 R66-69	0 Ω	Resistor, chip, 1/16W	0603	Std	Std
15	R55 R13 R21 R24 R25 R27 R30 R35 R46 R48 R51 R11 R56 R62 R70	10.0 kΩ	Resistor, chip, 1/16W, 1%	0603	STD	STD
1	R61	10 kΩ	Resistor, Network 9 Pin, 10 kΩ, 200 mW, 2%	SIP-9	4309R-101-103LF	Bourns
1	R63	150 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
1	R64	249 kΩ	Resistor, chip, 1/16W, 1%	0603	Std	Std
Note s:	1. E&E Magnetic Products, Ltd.: Sales 852-29543333 Tel (Hong Kong) www.eleceltek.com US Sales Contact Darren Simmons 408-727-4223 Cell 707-363-2448 darren_a_simmon@eleceltek.com					
	1B. Würth Elektronik, Oliver Opitz, Oliver.Opitz@we-online.de					

6 Test Setup

6.1 Equipment

6.1.1 bqTESLA™ Receiver

Use the bq51013AEVM-764, -765 or Qi-compliant receiver to work with this EVM.

6.1.2 Voltage Source

Input voltage source must provide regulated dc voltage of 12 V and be able to deliver at least 1.0 A continuous load current; the current limit must be set to 2.0 A.

CAUTION

Safety Considerations of Voltage Source: To help assure safety integrity of the system and minimize risk of electrical shock hazard, always use a power supply providing suitable isolation and supplemental insulation (double insulated). Compliance to IEC 61010-1, Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use, Part 1, General Requirements, or its equivalent is strongly suggested, including any required regional regulatory compliance certification approvals. Always select a power source that is suitably rated for use with this EVM as referenced in this user manual.

6.1.3 Meters

Monitor the output voltage at the bq51013AEVM-764 test point, TP7, with a voltmeter. Monitor the input current into the load with an appropriate ammeter. You can also monitor the transmitter input current and voltage, but the meter must use the averaging function for reducing error due to communications packets.

6.1.4 Loads

A single load is required for 5 V with a maximum current of 1 A. The load can be resistive or electronic.

6.1.5 Oscilloscope

Use a dual-channel oscilloscope with appropriate probes to observe the COMM_DRV signal at bq51013AEVM-764 TP3 and other signals.

6.1.6 Recommended Wire Gauge

For proper operation, 22-AWG wire is recommended when connecting the bq500410AEVM-045 to the input supply and the bq51013AEVM-764 to the load.

6.2 Equipment Setup

- With the power supply OFF, connect the supply to the bqTESLA™ transmitter.
- Connect the V_{in} positive power source to J1, and connect the negative terminal of the V_{in} source to J2.
- Do not place the bqTESLA™ receiver on the transmitter. Connect a load to J3 with a return to J4, monitor current through load with an ammeter, and monitor the current to load at TP7. All voltmeters must be Kelvin connected (at the pin) to the point of interest.

6.2.1 Equipment Setup Diagram

The diagram in Figure 4 shows the test setup.




Figure 4. Equipment Setup

6.2.2 EVM Procedures

This section guides the user through a few general test procedures to exercise the functionality of the presented hardware.

6.2.2.1 Start-Up No Receiver

Turn on V_{IN} , and observe that the green, Power LED, D3, illuminates. Status LED, D4, is off until the power transfer starts.

Apply the scope probe to the test point, TP12, and observe single-pulse bursts approximately every 400 ms. This is an Analog Ping probing environment for the presence of a receiver placed on the TX coil.

6.2.2.2 Apply Receivers

Place the bq51013AEVM-764 EVM on the top of the transmitting coil. Align the centers of the receiving and transmitting coils across each other. In the next few seconds, observe that the Status LED, D4, illuminates green, indicating that communication between the transmitter and the receiver is established and that the power transfer has started.

- The TX buzzer sounds at the start of power transfer. Status LED, D4, flashes a green light during power transfer.
- Typical output voltage is 5 V, and the output current range is 0 mA to 1 A.
- Observe a continuous drive waveform on the test point, TP1, when power transfer is active; the frequency is between 110 kHz and 205 kHz depending on load.
- Make tests and measurements applicable to a normal 5-V power supply.

6.2.2.3 Efficiency

To calculate system efficiency, measure the output voltage, the output current, input voltage, and input current and calculate efficiency as the ratio of the output power to the input power. Connect voltage meters at the input and output of TX and RX (see Figure 4). Average the input current; the comm pulses modulate the input current, distorting the reading. See Figure 5 for efficiency.




Figure 5. Efficiency Versus Power Across Each Coil, bq500410AEVM-085 Transmitter and bq51013AEVM-764 Receiver




Figure 6. Efficiency Versus Power Center Coil 12-V Input Versus 5-V Input, bq500410-085 Transmitter and bq51013AEVM-764 Receiver

6.2.2.4 Parasitic Metal Object Detection (PMOD)

This is a safety feature used to detect the presence of a metal object on the charging pad near the TX coil, significant thermal rise is possible on the object. The PMOD circuit compares transmitter power with the power the receiver reports it has received. If the difference exceeds the threshold set by R40 a fault is declared. See the data sheet for additional information on this feature.

6.2.2.5 Thermal Protection, NTC

Thermal protection is provided by an NTC resistor connected to J6. At 1 V on the sense side, U9-2, the thermal fault is set, and the unit is shut down, The Status LED, D4, illuminates red. Typical resistor value for fault is 850 Ω . The system tries to restart in 5 minutes.

7 bq500410AEVM-045 Assembly Drawings and Layout

Figure 8 through Figure 13 show the design of the bq500410AEVM PCB. The EVM has been designed using a 4-layer, 2-oz, copper-clad circuit board 13.9 cm x 13.3 cm with all components on the top side to allow the user to easily view, probe, and evaluate the bq500410A control IC in a practical application. Moving components to both sides of the PCB or using additional internal layers can offer additional size reduction for space-constrained systems. Gerber files are available for download from the EVM product folder.

A 4 layer PCB design is recommend to provide a good low noise ground plane for all circuits. 2-layer PCB presents a high risk of poor performance.

Coil Grounding – A ground plane area under the coil is recommended to reduce noise coupling into the receiver. The ground plane for the EVM is slightly larger than the coil footprint and grounded at one point back to the circuit area.

The cover thickness is 0.93 inch, or 2.4 mm is the z-gap thickness for the transmitter.




Figure 7. Placement




Figure 8. Assembly Top




Figure 9. Top Silk




Figure 10. Top Layer




Figure 11. Layer 2




Figure 12. Layer 3




Figure 13. Bottom Layer

8 Reference

For additional information about the bq500410AEVM-045 low-power, wireless, power evaluation kit from Texas Instruments, visit the product folder on the TI Web site at <http://focus.ti.com/docs/toolsw/folders/print/bq500410A.html>.

EVALUATION BOARD/KIT/MODULE (EVM) ADDITIONAL TERMS

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions:

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit www.ti.com/esh or contact TI.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

REGULATORY COMPLIANCE INFORMATION

As noted in the EVM User's Guide and/or EVM itself, this EVM is subject to the Federal Communications Commission (FCC), Industry Canada (IC) and European Union CE Mark rules.

FCC – FEDERAL COMMUNICATIONS COMMISSION Part 18 Compliant

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:—Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: There is no required maintenance of this device from a FCC compliance perspective.

IC – INDUSTRY CANADA ICES-001 Compliant

This ISM device complies with Canadian ICES-001.

Cet appareil ISM est conforme à la norme NMB-001 du Canada.

European Union CE Mark

This ISM device complies with Directive 2004/108/EC of the European Parliament and of the Council of 15 December 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility and repealing Directive 89/336/EEC – the **EMC Directive, tested to EN55011: 2007, Industrial Scientific and Medical (ISM) radio-frequency equipment.**

EVALUATION BOARD/KIT/MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMERS

For Feasibility Evaluation Only, in Laboratory/Development Environments. Unless otherwise indicated, this EVM is not a finished electrical equipment and not intended for consumer use. It is intended solely for use for preliminary feasibility evaluation in laboratory/development environments by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems and subsystems. It should not be used as all or part of a finished end product.

Your Sole Responsibility and Risk. You acknowledge, represent and agree that:

1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.
2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
3. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.
4. You will take care of proper disposal and recycling of the EVM's electronic components and packing materials.

Certain Instructions. It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

Agreement to Defend, Indemnify and Hold Harmless. You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

Safety-Critical or Life-Critical Applications. If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2013, Texas Instruments Incorporated

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Applications Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Automotive and Transportation	www.ti.com/automotive
Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Video and Imaging	www.ti.com/video

TI E2E Community

e2e.ti.com